



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-70203

FRONT VALANCE

CHEVY "S" SERIES

1994 - 1997

GENERATION 1

### INSTALLATION INSTRUCTIONS

**NOTE: Fit all parts before painting ( See Special Instructions For Paint Prep. ) Parts that have been installed, preped, or painted are not returnable.**

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

#### PARTS LIST

1	Front Valance	1	Instruction Sheet	1	Street Scene Decal
---	---------------	---	-------------------	---	--------------------

#### TOOL LIST

Drill Motor, 1/4" Drill Bit, 1/2" Drive Ratchet, 1/2" Drive 3" Extension, 1/2" Drive #50 Torx Socket, 1/2" Drive 15mm Socket, Small Flat Blade Screwdriver, 3/8" Drive Ratchet, 3/8" Drive 6" Extension, 3/8" Drive 7mm Socket, 3/8" Drive 10mm Socket, Safety Glasses

1. Before beginning installation be sure to wear proper eye protection.
2. Open the hood. Remove the four 7mm screws fastening the grille at the top. Remove the two remaining 7mm screws in the center of the grille above and below the "Bowtie" or "GMC" emblem. Set aside.
3. Gently pull grille from the bottom to release the clips attaching it to the core support. ( Be careful not to scratch the bumper when removing ). TIP: lay masking tape over the top surface of the bumper.
4. Remove bumper and air dam as an assembly, by first removing the 15mm bolts located at the right and left fender opening attaching the brace from the frame to the bumper.
5. With a #50 Torx socket remove the four bolts attaching the bumper to the frame below grille opening.
6. Set the bumper on a protective surface and remove the ten bolts securing the air dam to the bumper.
7. Remove the ten speed nut clips from the air dam by inserting a small flat blade screwdriver under the the locking tab to release the clip and pull outward.
8. Mark the new valance using the old one as a template, and drill holes thru and install clips. ( **NOTE:** If clips do not lock in, gently bend locking tabs down ).
9. Attach the new valance to the bumper with the 10mm bolts removed in step 6. **NOTE:** If installing light kit, do so at this time.
10. Install the bumper and valance onto the truck. Finger tighten all bolts and align bumper. Tighten all bolts securely.
11. Install grille assembly by first snapping the bottom into the core support and then attaching the six 7mm screws that were removed in step two.