



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-70208

1982 - 1993

GM "S" SERIES

FRONT VALANCE

GENERATION 1

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Front Valance	1	Instruction Sheet	1	Street Scene Decal
1 FT.	1/2" 2 Sided Tape				

TOOL LIST	
Miss. Hand Tools, Drill Motor, Drill Bits	

1. Remove the front valance from the underside of bumper if so equipped.
2. Set the Street Scene Valance mounting side to mounting side of OEM valance and mark mounting holes. Drill holes.
3. If vehicle has no OEM valance, set the Street Scene Valance under the bumper and clamp to bumper, Mark and drill holes.
4. Clean the side surfaces of the Street scene Valance and attach the two sided tape.
5. Attach the valance to the bumper using the hardware removed in step 1. If no valance was present, it will be necessary to purchase some bolts and nuts at your local hardware store.
6. Lift up the corners and remove the tape back and adhere the the valance corners to the bumper.