



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, Ca. 92626
Phone (714) 426-0590 Fax (714) 426-0591

950-70215
2004
CHEVY COLORADO
&
GMC CANYON
X-CAB SIDE SKIRT KIT
6 PC SET
SUPER CAB

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, prepped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
6 PC	Side Skirt Set	1	Instruction Sheet	25 FT.	1/2" Two Sided Tape
1	Street Scene Decal	1	Urethane Prep Sheet	14	# 10 Black Washerhead Screws

TOOL LIST	
Drill Motor, 1/8" Drill Bit, Masking Tape, Scotch Brite Pad, Alcohol	

NOTE:

If possible raise truck to a better work height, (jack truck up and set on jack stands).

1. Open front doors and rear doors of cab. With the aid of a helper set the cab skirt to cab and tape into position. Check fit for alignment at front and rear. Drill two holes through front of skirt into the front wheel well lip. Lay a tape line on door sill above skirt, Remove skirt from vehicle. Scuff up paint on body approximately one inch wide, 1/4" inch below tape line.
2. Set the front bed skirt onto vehicle. Tape into position drill two holes through edge of skirt and into lip of wheel well. Lay a tape line on bedside just above skirt. Remove skirt scuff up paint with scotch brite pad approximately one inch wide, 1/4" inch below tape line.
3. Set the rear bed skirt to bed, again tape into position. Make sure rear of skirt is positioned properly. Drill holes through edge of skirt and into lip of wheel well. Lay a tape line above skirt, Remove skirt. Using a scotch brite pad scuff up paint on body approximately one inch wide 1/4" below tape line.
4. After parts have been fitted thoroughly paint to match. Follow urethaneprep instructions. Make sure you clean the back side of skirts as well as the front side.
5. Wipe off back lips of skirts with alcohol or adhesion promoter. Apply two sided tape to backsides. Wipe off the areas scuffed on truck with alcohol. Attach skirts to vehicle with screws through holes drilled when pre fitting. Grasp backing on tape and pull while applying pressure on skirt to body. If skirts do not want to adhere to body, re-clean areas and apply new tape.