



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
 Costa Mesa, Ca. 92626
 Phone (714) 426-0590 Fax (714) 426-0591

950-70218
 2004
 CHEVY COLORADO
 &
 GMC CANYON
 FRONT BUMPER COVER
 SS STYLE GEN 2

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Bumper Cover	1	Instruction Sheet	4	# 10 X 3/4" S/S Screws # 11034
1	Street Scene Decal	1	Urethane Prep Sheet		

TOOL LIST
Drill Motor, 1/2" Drill Bit, 5/64" Drill Bit, Phillips Screwdriver, Socket Set

1. Remove the front grille assembly, this is achieved by unsnapping the grille shell from body by gently pulling. Disconnect the light plugs and remove.
2. Remove the lower valance beneath bumper.
3. Remove the two upper bumper bolts.
4. Slide the bumper cover over the front bumper align bumper cover with body. Mark locations of bumper bolts. Remove and drill with 1/2" drill bit. Re-install bumper cover and install top bolts. Drill two 5/64 holes through bumper cover and into each corner of bumper. Install the stainless steel screws provided.
5. Re-install front grille assembly.