



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

INSTALLATION INSTRUCTIONS

950-70219

2004

CHEVY COLORADO

&

GMC CANYON

REAR WING ONLY

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Tailgate Wing	1	Instruction Sheet	1	Street Scene Decal
10 FT.	1/2" Two Sided Tape	1	Urethane Prep Sheet		

TOOL LIST	
NONE	

NOTE:

CHECK FITMENT OF TAILGATE WING BEFORE PAINTING. FOLLOW URETHANE PAINTING INSTRUCTIONS

1. Remove factory tailgate piece. Clean top edge of tailgate with alcohol.
2. Clean the back side of wing with alcohol and apply the two sided tape.
3. Set the wing on tailgate and remove the two sided tape. Apply pressure at tape areas.