



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, CA. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-70221

2014-2015

CHEVY SILVERADO 1500

FRONT BUMPER COVER

"SS" STYLE

URETHANE

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

******* NOTE: THIS WILL NOT FIT 2014-2015 GMC SIERRA 1500 TRUCKS!!!*******

Check fit all body parts PRIOR to paint. Follow urethane prep instructions before painting.

Take your time and pre-fit all pieces so that they will have a tight fit to the body.

VERY IMPORTANT! Read and understand all directions and check the following parts list before starting installation.

| PARTS LIST | | | | | |
|------------|--------------------|---|---------------------|-------|--------------------------|
| 1 | Front Bumper Cover | 1 | Instruction Sheet | 4 | Stainless Steel Screws |
| 2 PKS | Adhesion Promoter | 1 | Urethane Prep Sheet | 9 FT. | 1/2" Wide Two Sided Tape |

| INSTALLATION TOOL LIST | |
|---|--|
| Drill Motor, 1/8" Drill Bit, Phillips Head Screwsdriver | |

1. Begin by removing the factory bumper cover. First remove the 5 bolts located at each wheel well. **(Fig. 1)**
Then carefully unclip the bumper cover from the bumper by depressing each retaining tab and gently pulling towards the front of the vehicle. **(Fig. 2)**
2. Disconnect the fog lights if equipped.
3. Remove front engine bay cover by removing clips and 4 upper grille retaining bolts. **(Fig.3)**
4. Remove the grille. There are 4 lower grille retaining bolts **(Fig. 4)** and two clips.
The clips are located near the rear of the headlight assembly **(Fig. 5)**. Lift up and out to remove.
5. Remove the bumper assembly. Remove the 4 bumper side support bolts (two per side) **(Fig. 6)**, then remove the two bolts attaching the bumper to each frame horn **(Fig. 7)**.
6. Remove bottom air dam. Remove the 14 bolts attaching air dam to bumper **(Fig.8)**.
7. Remove bumper center. Remove the 10 bolts attaching it to bumper and the one clip per side.



