



# STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, CA. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-70318  
2003-2007  
NISSAN 350Z  
FRONT FASCIA  
URETHANE

## INSTALLATION INSTRUCTIONS

**NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.**

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Rear Valance	1	Instruction Sheet	1	Urethane Prep Sheet
14	Push-in Fastener(18378)				

TOOL LIST
Drill Motor, Assorted sockets and wrenches, Sandpaper/scotch brite

1. Start by removing the clips on the topside of the front fascia **(FIG.1)**
2. Remove the screws that join the front fascia fender well cover **(FIG.2)**
3. Next you will need to remove the various screws on the underside of the vehicle holding on the splash guard. **(FIG.3)**
4. Reinstall the new fascia onto the vehicle as the stock fascia was removed. You will need to drill out the indentations that mark the guide holes first.

**NOTE: IF YOU OWN 2003-2006 Z YOU CAN REUSE ALL OF YOUR STOCK HARDWARE. IF YOU OWN A 2007+ Z YOU WILL NEED TO USE THE PROVIDED SCREWS FOR ATTACHING THE BUTTON OF THE FASCIA TO THE SPLASH GUARD. BE SURE TO MAKE PILOT HOLES BEFORE USING THE SELF-TAPPING SCREWS.**

5. Done! Enjoy the looks of your new Street Scene front fascia.

