



# STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue  
 Costa Mesa, CA. 92626  
 Phone (714) 426-0590 Fax (714) 426-0591

**950-70319**  
**2003-2007 NISSAN 350Z**  
**GEN 2 FRONT SPLITTER**  
**FOR 950-70318 BUMPERCOVER**  
**URETHANE**

## INSTALLATION INSTRUCTIONS

**NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.**

### NOTE:

Check fit all body parts **PRIOR** to paint. Follow urethane prep instructions before painting. Take your time and pre-fit all pieces so that they will have a tight fit to the body.

**VERY IMPORTANT!** Read and understand all directions and check the following parts list before starting installation.

### NOTE:

The 950-70338 Wing is mounting on the rear window glass just below the roof line.

PARTS LIST					
1	Front Splitter	1	Instruction Sheet	6	M6X25MM Hex Bolts
2	Turnbuckles	1	Urethane Prep Sheet	8	Self Tapping Screws
6	M6 Nuts	12	6MM Washers		

TOOL LIST
Assorted Sockets & Wrenches, Phillips and Flat Head Screw Drivers, Drill & Drill Bits

1. Jack up the front of the car and support with jack stands. A lift would be ideal.
2. Test fit splitter onto fascia using picture (Fig 1) as your guide.



**FIG 1**

3. Once satisfied with placement use duct tape to hold splitter in place and drill holes for the M6 bolts through both splitter and fascia in 3 places on either side of the splitter opening. As shown in (Fig 2) as well as the center hole for the center support.





4. Install M6 bolts with washers through spillter/fascia and tighten with M6 nut and washer. The longer bolt will go through the center support
5. Test fit stainless steel turnbuckles as shown in (fig 3) and mark mounting hole locations for drilling . Drill small pilot holes through fascia and splitter and mount turnbuckles as shown in (Fig 3) repeat on other side.
6. Adjust turnbuckles to elminate play and stiffen up splitter.



7. Done! Enjoy your new Street Scene front lip!