

STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue Costa Mesa, Ca. 92626 Phone (714) 426-0590 Fax (714) 426-0591 950-70327 2003 - 2006 NISSAN 350 Z ROOF WING URETHANE

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

NOTE:

Check fit all body parts PRIOR to paint. Follow urethane prep instructions before painting. Take your time and pre-fit all pieces so that they will have a tight fit to the body.

VERY IMPORTANT! Read and understand all directions and check the following parts list before starting installation.

NOTE:

The 70327 Wing is mounting on the rear window glass just below the roof line.

PARTS LIST						
1	Rear Window Wing	1	Instruction Sheet	8 FT	1/2" Wide Two Sided Tape	
2 PKGS	3M Adhesion Promoter	1	Urethane Prep Sheet			

TOOL LIST	

- 1. Set the Wing on the rear glass to see where it will be positioned. Mark the glass and remove the wing. Clean the glass with a wax and grease remover. Apply the adhesion promoter to the area marked.
- 2. Clean the back side of wing with a scotch brite pad with a wax and grease remover. Apply the 3-M adhesion promoter to the tape apply area. Install the two sided tape. DO NOT remove the backing at this time.
- 3. Set the wing on vehicle and remove the tape backing. Apply pressure on wing over the tape.