



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, CA. 92626
Phone (714) 426-0590 Fax (714) 426-0591

950-70505
2002 - 2005
DODGE RAM 1500
GENERATION 1
BUMPER COVER URETHANE

INSTALLATION INSTRUCTIONS

VERY IMPORTANT! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Bumper Cover	1	Instruction Sheet	1	Urethane Paint Prep. Sheet

TOOL LIST
Flat Blade Screwdriver, 8MM Torx Socket, Ratchet, Drill Motor, 1/4" Drill Bit

1. Starting at one side slide the bumper cover over the bumper and then pull it across over the other side.
2. Drill two holes through the bumper cover at each side to match the mounting holes of the top strip removed in step 1. Install the torx fasteners in the holes drilled.