



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, CA. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-70611
2015+ FORD F-150
ROLL PAN
URETHANE

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See special instructions for paint Prep.) Parts that have been installed, prepped, or painted are not returnable.

VERY IMPORTANT! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Urethane Roll Pan	1	Instruction Sheet	5	Washer Head Screws # 71834
1	Urethane Paint Sheet	2	Adhesion Promoter	7 FT.	1/2" Wide Two Sided Tape

TOOL LIST	
Drill Motor, Phillips Screwdriver, Safety Glasses, 5/32" Drill Bit, Masking Tape	

1. Remove factory bumper if so equipped.
2. Remove tailgate by lifting the spring tabs on the cable and removing the limit cables from the bed while holding the tailgate. Close the tailgate about 1/3 of the way and pull the right side out and while holding the tailgate surcurely pull it out and away from the left side of bed.
3. Clean the back side right and left corners of rollpan that wraps around with alchol and apply the two sided tape to the body contact area.
4. Set the rollpan to the back of bed. Tape into position with masking tape. Drill a hole in the center of rollpan flange and into bed. Attach with one of the provided screws. Drill a hole one inch from each end and centered between. Fasten rollpan securely with remaining screws. Pell off the vinyl backing on the two sided tape and secure the roll pan to the bed corners.
5. Re-install the tailgate.
6. Enjoy your new Street Scene roll pan!