



# STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue  
 Costa Mesa, Ca. 92626  
 Phone (714) 426-0590 Fax (714) 426-0591

950-70703  
 2003-04  
 HOOD COWL  
 FORD  
 EXPEDITION

## INSTALLATION INSTRUCTIONS

**NOTE: Fit all parts before painting ( See special instructions for paint Prep. ) Parts that have been installed, prepped, or painted are not returnable.**

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

**NOTE : NO DRILLING NECESSARY NOTE: NO CUTTING NECESSARY**

PARTS LIST					
1	Hood Cowl	1	Instruction Sheet	4	71093 CLIP
2	Plastic Retainers	1	Street Scene Decal		

TOOL LIST	
Ratchet, 10 MM Socket, Small Flat Blade Screwdriver, Safety Glasses	

1. Before beginning installation be sure to wear proper eye protection.
2. Remove wiper arm assemblies from vehicle.
3. Remove push in fasteners from factory wiper cowl located on either end and the 3 washer sprayers. Carefully lift off both pieces to factory cowl.
4. With help from someone holding the hood remove the 2 bolts that attaches the hood to the hinge on the driver side only. Carefully lift hood off the hinge and place new wiper cowl into place.
5. Re-install bolts into hood and secure to hinge.
6. Re-install washer sprayers into new cowl.
7. Using plastic retainers provided, push into oval holes in wiper cowl to fasten to vehicle. See illustration, location **A** and **B**.
7. With the 4 (71093) clips provided attach wiper cowl in center. Space clips evenly along fron edge of cowl. See illustration for clip location.
8. Re-install wiper assemblies.

