



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, Ca. 92626
Phone (714) 426-0590 Fax (714) 426-0591

950-70706
1997 - 2003
FORD F-150 FLAIRSIDE
ROLL PAN

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Roll Pan	1	Instruction Sheet	5	Phillips Head Sheet Metal Screws
		1	Street Scene Decal	2 FT.	1/2" Wide Double Sided Tape
				1	Urethane Prep Sheet

TOOL LIST	
Drill Motor, Phillips Screwdriver, Safety Glasses, 5/32" Drill Bit, Masking Tape	

1. Remove bumper and all attaching brackets.
2. Place roll pan against the bed of truck. Align roll pan with body. Using masking tape, tape roll pan into position.
3. Drill five 5/32 holes through mounting flange and into bed. Secure with the screws provided.
4. Remove roll pan and paint to match. Follow urethane paint prep. Instructions. Remove and paint rear " steps " at this time.
5. Clean the area on the inside corners of roll pan. Apply the two sided tape.
6. Attach roll pan to bed. Pull back the corner and remove the cover on the two sided tape and press roll pan to body corners.