



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-70708

2000 - 2005

FORD F-350

WIPER COWL

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See special instructions for paint Prep.) Parts that have been installed, prepped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST

1	Wiper Cowl	1	Instruction Sheet	1	Fiberglass Paint Prep Sheet
		1	Street Scene Decal	4	Adhesive Backed Clips (005-00493)
2	# 8 x 3/4" Screws (005-00841)			6	Push In Fasteners (005-18378)

TOOL LIST

Phillips Screwdriver, 10 MM Wrench, Drill Motor, 5/64" Drill Bit, 5/16" Drill Bit, Flat Blade Screwdriver, Masking Tape

1. Slide the ABS wind deflector up on the antenna to expose the hex area. Remove antenna.
2. Lift the wiper arm to the up position. Lift the small tab on the base of wiper arm and remove wipers.
3. Remove the eight phillips head screws across the top of the factory wiper cowl.
4. Open hood. Remove the six push in fasteners across the bottom of the factory wiper cowl. Use a flat blade screwdriver to pry out.
5. Remove wiper cowl at the same time disconnecting windshield wash hose.
6. Remove the windshield washer squitters from the factory wiper cowl and install on the Street Scene smooth wiper cowl. Use the adhesive backed clips supplied to support the washer fluid hose. Clean the area before adhering.
7. Install the Street Scene smooth wiper cowl to vehicle. Install antenna. Use masking tape and tape into position. Close hood and check for positioning. Re-position as necessary. Re-tape into place. Drill a 5/64" hole at each corner of wiper cowl in the recessed hole and into body. Install the two # 8 X 3/4" screws provided.
8. Open hood. Drill six 5/16" holes through wiper cowl and into body. Install the six " PUSH IN " fasteners provided to secure wiper cowl. If you want you can drill the holes where the factory fasteners were.
9. Re-install wiper arms. Make sure arms are secure before operating.