



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue  
 Costa Mesa, CA. 92626  
 Phone (714) 426-0590 Fax (714) 426-0591

950-70714  
 2013-2014 FORD MUSTANG  
 GENERATION 2  
 FRONT LIP SPOILER  
 URETHANE

### INSTALLATION INSTRUCTIONS

**NOTE: Fit all parts before painting (See special instructions for paint Prep.) Parts that have been installed, prepped, or painted are not returnable.**

**VERY IMPORTANT!** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Urethane Spoiler	1	Instruction Sheet	1	Urethane Paint Prep Sheet
3 FT.	3/4" Double Sided Tape	4	Self Tapping Screws	2	Adhesive Promoter
3 FT.	1/2" Double Sided Tape				

TOOL LIST
Drill with Phillips Head bit, Scotch Brite/Sandpaper

- After the front lip spoiler is prepped and painted, double sided tape should be applied to the indentation on the inside of the front spoiler. This surface has to be CLEAN and DRY for the tape to properly adhere. A residual free cleaner is recommended (e.g. Wurth Clean Solve) to prepare the surface. The surface of the vehicle should also be prepped and cleaned to for proper adhesion. **(Fig.2)** For best results after cleaning use the adhesion promoter provided to the areas where the tape will be used. When applying tape, make sure the tape is smooth and wrinkle free. It is best to use the multiple small pieces on the long section rather than 1 long piece.



**FIGURE 1**

- After applying the tape pul back approximately 1 inch of the protective covering from the tape on each end. Make sure the film is sticking out. **(Fig. 2)** Place the front lip spoiler GENTLY on the vehicle and make sure you have it positioned correctly. It is good to have someone help you with this. Remember when using adhesion promoter you will not get a second chance! So make sure it is on correctly. While holding it in position, pull the tabs you created while applying light downward pressure. Continue this taking care not to tear off the tabs by pulling to hard. After all the film is removed, apply firm pressure all around to insure the tape has bonded properly .



3. Use the provided self tapping screws to secure the back of the spoiler onto the vehicle. **(Fig.2 Arrow)**
4. Done! Enjoy you front lip spoiler!