



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, Ca. 92626
Phone (714) 426-0590 Fax (714) 426-0591

950-70728
1999 - 2004
CHEVY SILVERADO
&
GMC SIERRA
REAR WING ONLY

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

| PARTS LIST | | | | | |
|------------|---------------------|---|---------------------|---|--------------------|
| 1 | Tailgate Wing | 1 | Instruction Sheet | 1 | Street Scene Decal |
| 10 FT. | 1/2" Two Sided Tape | 1 | Urethane Prep Sheet | | |

| TOOL LIST | |
|-----------|--|
| NONE | |

NOTE:

CHECK FITMENT OF TAILGATE WING BEFORE PAINTING. FOLLOW URETHANE PAINTING INSTRUCTIONS

1. Remove factory tailgate piece. Clean top edge of tailgate with alcohol.
2. Clean the back side of wing with alcohol and apply the two sided tape.
3. Set the wing on tailgate and remove the two sided tape. Apply pressure at tape areas.