



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, Ca. 92626
Phone (714) 426-0590 Fax (714) 426-0591

950-70737
2005 - 2006
FORD MUSTANG
SIDE AIR DUCTS

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

NOTE:

**THESE ARE NOT FUNCTIONING AIR DUCTS
CHECK FIT ALL PARTS PRIOR TO PAINTING**

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Right Air Duct	1	Instruction Sheet	6 FT	1/2" Wide Two Sided Tape
1	Left Air Duct	1	Urethane Prep Sheet	1	Street Scene Decal
1	Black Out Decal Right Side Air Duct			2 PKGS	3M Adhesion Promoter
1	Black Out Decal Left Side Air Duct				

TOOL LIST	

1. After fitting the side air ducts to body, paint to match.
2. Install the " Black Out " decal to the air intake side to simulate an opening.
3. Clean the area of body with a wax and grease remover.
4. Clean the back side of air duct and apply the adhesion promoter. Apply the two sided tape to the tape edge. DO NOT remove the tape backing at this time.
5. Set air duct to body side and remove tape backing. Apply pressure on air duct over the tape area.