



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue  
Costa Mesa, Ca. 92626  
Phone (714) 426-0590 Fax (714) 426-0591

950-70738  
2005  
FORD MUSTANG  
REAR SIDE WINDOW DUCTS  
GENERATION 3

### INSTALLATION INSTRUCTIONS

**NOTE:** Fit all parts before painting ( See Special Instructions For Paint Prep. ) Parts that have been installed, preped, or painted are not returnable.

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Left Window Duct	1	Instruction Sheet	8 FT.	1/2" Two Sided Tape
1	Right Window Duct	1	Urethane Prep Sheet	1	Street Scene Decal
1 Set	Black Out Decal Front & Rear For Window Ducts			2 PKGS	3M Adhesion Promoter
1 Set	Black Out Decal Front & Rear For Window Ducts				

TOOL LIST	
Sand Paper, Adhesive Promoter	

1. Thoroughly clean both sides of the window duct set.
2. Please find the tape line extending around the perimeter of the back side of each window duct. Scuff this surface and apply adhesive promoter. Install strips of double sided mounting tape in the areas indicated. ( Image I )

Image I



3. Thoroughly clean the rear side windows of all debris, dust and wax.
4. Remove, red plastic backing tape and adhere air ducts to rear windows. ( Image II )

Image II



Special NOTE: These products are manufactured in tough, durable polyurethane. Please follow paint suppliers prep and paint instructions to insure proper paint adherence. Paint the front air intake side of duct black to simulate an opening.

5. Install the " Black Out " decal to the front and rear air intake side of duct to simulate an opening.