



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, Ca. 92626
Phone (714) 426-0590 Fax (714) 426-0591

950-70751
2006
FORD FUSION
FRONT SPOILER

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Front Spoiler	1	Instruction Sheet	8 FT	1/2" Wide Two Sided Tape
		1	Urethane Prep Sheet	1	Street Scene Decal
1 EA.	Driver Side & Passenger Side Black Out Decal			3 PKGS	3M Adhesion Promoter

TOOL LIST	

NOTE:

Check fit all body parts PRIOR to paint. Follow urethane prep instructions before painting. Take your time and pre-fit all pieces so that they will have a tight fit to body.

1. Set front spoiler on front of car to see mounting location. Clean the area where the spoiler will attach with a wax & grease remover.
2. Set spoiler on a covered bench or table. Remove all paint from the tape apply area. Clean the area with a scotch brite pad and wax and grease remover.
3. Wipe area with the adhesion promoter. Apply the tape along the top edge and along the edge that goes into the center opening. Do not remove the tape backing at this time. Lift the corners of the tape backing.
4. Install the " Black Out " decals to recessed areas below the signal lamps after painting.
4. Set the spoiler onto the front end. Position into place. With the aid of another person hold into position. When you are satisfied with the position, pull the corner of the tape backing and remove the backing while applying pressure over the tape.