



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
 Costa Mesa, Ca. 92626
 Phone (714) 426-0590 Fax (714) 426-0591

950-70757
2006
FORD FUSION
REAR DECK WING
GENERATION 1

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

NOTE:

Check fit all body parts PRIOR to paint. Follow urethane prep instructions before painting. Take your time and pre-fit all pieces so that they will have a tight fit to the body.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Rear Deck Wing	1	Instruction Sheet	10 FT	1/2" Wide Two Sided Tape
2 PKGS	3M Adhesion Promoter	1	Urethane Prep Sheet	1	Street Scene Decal

TOOL LIST

1. Set the Rear Deck Wing at the edge of the deck lid. The rear mounting edge of wing will be on the downward edge of the deck lid. Check for a tight fit. If necessary grind or sand the bottom side of wing for a tight fit. NOTE: A tight fitment is necessary for good tape adhesion. When you are completely satisfied with the fit the wing is ready to clean to paint. Follow instructions when painting.
2. Clean the tape apply edge on the back side of the wing with a scotch brite pad and wax & grease remover. Prime this area with the 3-M Adhesion promoter. Install the two sided tape. DO NOT remove the backing at this time. Lift the corners of the tape backing at this time.
3. Set the wing on the deck lid into the position that was previously fitted too. Hold the Deck Wing in position and grasp the corner of the tape backing and pull to remove while at the same time applying pressure to the tape.