



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, Ca. 92626
Phone (714) 426-0590 Fax (714) 426-0591

950-70759
2006
FORD FUSION
REAR WINDOW WING

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

NOTE:

Check fit all body parts PRIOR to paint. Follow urethane prep instructions before painting. Take your time and pre-fit all pieces so that they will have a tight fit to the body.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

NOTE:

The 70759 Wing is mounting on the rear window glass just below the roof line.

| PARTS LIST | | | | | |
|------------|----------------------|---|---------------------|------|--------------------------|
| 1 | Rear Window Wing | 1 | Instruction Sheet | 8 FT | 1/2" Wide Two Sided Tape |
| 2 PKGS | 3M Adhesion Promoter | 1 | Urethane Prep Sheet | 1 | Street Scene Decal |
| | | | | | |

| TOOL LIST | |
|-----------|--|
| | |

1. Set the Wing on the rear glass to see where it will be positioned. Mark the glass and remove the wing. Clean the glass with a wax and grease remover. Apply the adhesion promoter to the area marked.
2. Clean the back side of wing with a scotch brite pad with a wax and grease remover. Apply the 3-M adhesion promoter to the tape apply area. Install the two sided tape. DO NOT remove the backing at this time.
3. Set the wing on vehicle and remove the tape backing. Apply pressure on wing over the tape.