



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue  
Costa Mesa, Ca. 92626  
Phone (714) 426-0590 Fax (714) 426-0591

950-70761  
2005 - 2008  
FORD MUSTANG GT  
FRONT CHIN SPOILER

### INSTALLATION INSTRUCTIONS

**NOTE:** Fit all parts before painting ( See Special Instructions For Paint Prep. ) Parts that have been installed, preped, or painted are not returnable.

#### NOTE:

Check fit all body parts **PRIOR** to paint. Follow urethane prep instructions before painting. Take your time and pre-fit all pieces so that they will have a tight fit to the body.

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Front Chin Spoiler	1	Instruction Sheet	2	Adhesive Promoter
1	Street Scene Decal	1	Urethane Prep Sheet	8 FT	1/2" Wide Two Sided Tape

TOOL LIST	
Drill Motor, 3/16" Drill Bit, Phillips Screwdriver	

1. Clean the back side of spoiler where it will contact vehicle with an non - oil base cleaning solvent. Wipe the area with the adhesive promoter. Apply the two sided tape but DO NOT remove the backing at this time.
2. Set the spoiler to front of vehicle. Note position of the tape edge to body. Wipe the body with adhesion promoter.
3. Remove the two phillips head screws at the bottom of the inner fenders. Drill two 3/16" holes in the spoiler to match with the holes in inner fender.
4. Attach spoiler ends using the screws removed in step 3. Remove the tape backing and secure spoiler to body buy applying pressure over the tape edge.