



# STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue  
 Costa Mesa, Ca. 92626  
 Phone (714) 426-0590 Fax (714) 426-0591

950-70766  
 2005 - 2008  
 FORD MUSTANG GT  
 FRONT SPOILER  
 GENERATION 4

## INSTALLATION INSTRUCTIONS

**NOTE: Fit all parts before painting ( See Special Instructions For Paint Prep. ) Parts that have been installed, preped, or painted are not returnable.**

### NOTE:

**Check fit all body parts PRIOR to paint. Follow urethane prep instructions before painting. Take your time and pre-fit all pieces so that they will have a tight fit to the body. VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Front Spoiler	1	Instruction Sheet	10 FT	1/2" Wide Double Sided Tape
1	Street Scene Decal	1	Urethane Prep Sheet	6	Stainless Screws #10 PN 11034
2PGK	Adhesion Promoter				

TOOL LIST	
Drill Motor, 1/8" Drill Bit	

Pre-fit all pieces to the vehicle. Once you are assured you have the right body styling kit you may proceed. If uncertain call SSE to double check part number with your application. We highly recommend using masking tape anywhere the body kit will be touching the vehicle body to prevent scratches during pre-fit. Do any sanding, filing, or spacing necessary ( BEFORE PAINTING ) for a clean tight fit.

**NOTE: Parts that have been drilled, installed, or painted are not returnable.**

1. After the front spoiler has been pre-fitted prepped and painted the double sided tape should be applied to the indentation on the inside for the front spoiler. This surface has to be clean and dry for the tape to properly adhere. Wipe the tape surface with the adhesion promoter. When applying tape make sure that tape is smooth and wrinkle free.
2. The surface of the vehicle should also be preped in the same manner.
3. After applying the tape, pull back approximately on inch of protective covering from the tape on each end. Make sure the film is sticking out.
4. Place the spoiler gently on the vehicle and make sure you have it positioned correctly. Once you are certain hold into position and pull the tabs you created while applying light downward pressure. Continue this taking care not to tear off the tabs by pulling to hard. After all the film is removed apply firm pressure all around to insure the tape has bonded properly.
5. Drill three 1/8" pilot holes onto both ends of the front spoiler ( Where spoiler wraps around the corner of bumper ) and secure using the screws provided.