



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-70787
1993 - 1996
MITSUBISHI PICKUP
FRONT VALANCE

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Street Scene Valance	1	Instruction Sheet	10	1/4-20 Nyloc Nuts
20	1/4" Flat washers	10	1/4-20 X 3/4" Bolts		

TOOL LIST	
Ratchet, 7/16" Wrench, Drill Motor, 1/4" Drill Bit	

1. Remove the OEM valance from truck.
2. Place the OEM valance and Street Scene valance mounting sides face to face.
3. Mark the hole location and drill a 1/4" hole.
4. Fasten the Street Scene valance with the screws provided.