



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-70823

2003 - 2004

FORD EXPEDITION

SIDE SKIRTS

### INSTALLATION INSTRUCTIONS

**NOTE:** Fit all parts before painting ( See special instructions for paint Prep. ) Parts that have been installed, prepped, or painted are not returnable.

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	RH Skirt	1	Urethane Prep. Sheet	14 FT.	1/2" Two Sided Tape
1	LH Skirt			8	Black Washer Head Screws # 10
1	Instruction Sheet	1	Street Scene Decal	2	Black Retainer

TOOL LIST	
Phillips Screwdriver, Safety Glasses, Drill Motor, 13/64 Drill Bit	

### NOTE: PRE-FIT BEFORE PAINTING

1. Set the side skirt to vehicle ( Skirts are marked on back side for location ). Identify the area on the cab that the two sided tape will be needed adhere too and clean properly.
2. Clean the back side of skirt and apply the two sided tape where needed, **DO NOT** remove the backing on the tape at this time. Remember you can not " **OVER CLEAN** " the area.
3. Set the skirt on the vehicle and lift one end of backing and pull away from tape while pressing skirt against body.
4. At front door jam place 2 # 10 washerhead screws one at the front of door and one at rear of door.
5. At rear door jam place 2 # 10 washerhead screws one at the front and one at the rear of door.
6. At the front wheel well drill a 13/64 hole and secure skirt to wheel well with one black retainer.