



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, Ca. 92626
Phone (714) 426-0590 Fax (714) 426-0591

950-70828
2004
FORD F-150 BUMPER COVER
WITH NO LIGHTS
GENERATION 2

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Bumper Cover	1	Instruction Sheet	10 FT.	1/2" Two Sided Tape
		1	Urethane Prep Sheet	4	Stainless Steel Phillips Head Screws

TOOL LIST	
Drill Motor, 3/16" Drill Bit, Phillips Head Screwdriver	

1. Remove the ABS air deflector below the bumper.
2. Clean the top side of bumper with alcohol.
3. Clean the inside top side of bumper cover with alcohol.
4. Apply the two sided tape across the top side of bumper.
5. Starting at one side of bumper hook the bumper corner and pull across and " snap " over the other side. Drill two holes on each side through bumper cover and into bumper. Secure with screws provided.
6. Lift top corner of bumper cover and grasp the vinyl covering on the two sided tape and remove while pressing across the top of bumper.