



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-70835

FORD F-150

2004

**UPPER BUMPER COVER
WITH 6" LIGHT HOLES
OFF ROAD STYLE**

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Bumper Cover	1	Instruction Sheet	1	Street Scene Decal
		1	Urethane Prep Sheet		

TOOL LIST	
7, 8, 10 MM Sockets, Extension, Ratchet, Drill Motor, 1/4" Drill Bit, 5/16" Drill Bit	

NOTE: Use Part Number 950-30035 6" Lights (**NOT INCLUDED**)

1. Remove the top bumper cover by removing the three attaching bolts located at each end by the fender well. Remove the two bolts from the support brace to the frame at inner fender. Open hood, remove the three horizontal bolts located in the center of bumper cover. Set bumper cover on a bench and transfer the internals to the SSE Bumper Cover. It will be necessary to trim internals to clear lights. Take your time here and drill all holes correctly. Make sure you also transfer the mounting reinforcements at each end.
2. If installing lights install them at this time.
3. Install bumper cover back on vehicle. Install all bolts first before tightening.