



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue  
Costa Mesa, Ca. 92626  
Phone (714) 426-0590 Fax (714) 426-0591

950-70837  
2003 - 2007  
FORD EXPEDITION  
GENERATION 2  
SIDE SKIRTS

### INSTALLATION INSTRUCTIONS

**NOTE:** Fit all parts before painting ( See Special Instructions For Paint Prep. ) Parts that have been installed, preped, or painted are not returnable.

#### NOTE:

Check fit all body parts **PRIOR** to paint. Follow urethane prep instructions before painting. Take your time and pre-fit all pieces so that they will have a tight fit to the body.

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	RT Side Skirt	1	Instruction Sheet	18 FT	1/2" Two Sided Tape
1	LT Side Skirt	1	Urethane Prep Sheet	1	Street Scene Decal
1	Urethane Paint Instructions			4 PKGS	3 M Adhesion Promotor

TOOL LIST	
Ratchet, Extension, 13 MM Socket	

1. Raise vehicle.
2. Remove the OEM steps by removing twelve 13 MM head bolts attaching the brackets to the body on each side.
3. Clean the back side of the side skirt where the tape will attach. Use acetone and a scotch brite pad. Wipe clean again. Apply the packet of adhesion promotor.
4. Install the two sided tape to side skirt. Make sure to apply tape to the ends where it will meet the under side of body.
5. Open doors and wipe clean the area where the side skirt will attach. Apply the packet of adhesion promotor. We can not stress enough on cleaning the areas of tape contact.
6. Install the side skirt to vehicle. Apply pressure over the taped areas. If you do not install properly the first time, New tape will have to be applied before re-installing.