



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, Ca. 92626
Phone (714) 426-0590 Fax (714) 426-0591

950-70838
2007
FORD EXPEDITION
EDDIE BAUER / LIMITED
REAR VALANCE

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

NOTE:

Check fit all body parts **PRIOR** to paint. Follow urethane prep instructions before painting. Take your time and pre-fit all pieces so that they will have a tight fit to the body.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Rear Valance	1	Instruction Sheet	3 PKGS	3-M Adhesion Promotor
2	Self Drilling Screws	1	Urethane Prep Sheet	1	Street Scene Decal
				1	Paint Prep Instructions

TOOL LIST	
Phillips Screwdriver, Masking Tape	

1. Tape the rear valance up to the body and mark it's location. Use masking tape for this.
2. Clean the paint area on body with a wax & grease remover.
3. Clean the valance where the tape will contact it in the same way as on the body. Clean again. We can not stress the importance of cleaning.
4. Apply the adhesion promotor to the tape contact area and apply the two sided tape.
5. Install the rear valance to vehicle making sure it is aligned properly. Install one screw in each rear wheel well thru the valance and into the fender lip.
6. If exhaust pipe has less than 3/4" clearance between pipe and valance, lower exhaust pipe as necessary.