



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-70841

2004

FORD F-150 SUPER CAB

6 PC SIDE SKIRT KIT

### INSTALLATION INSTRUCTIONS

**NOTE: Fit all parts before painting ( See Special Instructions For Paint Prep. ) Parts that have been installed, preped, or painted are not returnable.**

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
6 PC.	Side Skirt Kit	1	Instruction Sheet	1	Street Scene Decal
10 FT.	1/2" Two Sided Tape	1	Urethane Prep Sheet		
32	Silver Washer Head Screws				

TOOL LIST	
Drill Motor, 1/8" Drill Bit, Phillips Screwdriver, Razor Blade	

#### NOTE:

**PARTS MUST BE CLEANED PROPERLY FOR THE TWO SIDED TAPE TO ADHERE PROPERLY**

#### NOTE:

**Side skirt panels are secured with two sided tape and screws. Follow instructions completely DO NOT eliminate any screws. Make sure all body areas and skirt tape areas are properly cleaned for good adhesion.**

1. Remove the rock panels behind the rear wheel well openings.
2. Open doors.
3. Apply the two sided tape to the ends of the cab skirt panels. Position on cab and remove backing on two sided tape. Apply pressure to adhere tape. Drill a hole at each end of the panel that extends upward at the door openings while pushing the skirt panel inward making sure skirt is tight to body. Install the screws provided. Do the same at all door openings. At the front wheel well opening drill a hole through the skirt and into the wheel well lip. Fasten with the self taping screws provided. Fasten the rear of the side skirt by drilling a hole through side of skirt and into the body and install the screws provided. Drill hole with rear door open and use a long drill bit to get access between door & cab.
4. Apply the two sided tape to the front bed skirt panels. Position on bed and remove backing. At the rear wheel opening drill a hole into the side skirt and into the wheel well lip. Fasten with the screws provided. Drill two more holes equqly spaced between nad install screws.
5. Apply the two sided tape to the rear bed skirt panels. Position on bed and remove backing. At the rear wheel opening drill two holes into the wheel well lip. Fasten with two screws. At the rear of the skirt panel drill a hole from the under side ( where it cannot be seen ) into the bed. Fasten with the screws provided. Do the same on the opposite side.