



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
 Costa Mesa, Ca. 92626
 Phone (714) 426-0590 Fax (714) 426-0591

950-70847
 2009
 FORD F-150
**BUMPER COVER WITH
 FACTORY ROUND LIGHTS**

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

NOTE:

Check fit all body parts PRIOR to paint. Follow urethane prep instructions before painting. Take your time and pre-fit all pieces so that they will have a tight fit to the body.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

| PARTS LIST | | | | | |
|------------|--------------|---|---------------------|---|------------------------------------|
| 1 | Bumper Cover | 1 | Instruction Sheet | 2 | # 10 X 3/4" Stainless Steel Screws |
| | | 1 | Urethane Prep Sheet | 1 | Street Scene Decal |
| | | | | | |

| TOOL LIST |
|--|
| Drill Motor, Phillips Screwdriver, 5/32" Drill Bit, Large Flat Blade Screwdriver |

1. Remove the tow hooks if so equipped. Remove the two black ABS bumpers to the right and left of the center opening in bumper. Use a large flat blade screwdriver and pry away from bumper. Discard bumpers.
2. Install the bumper cover by slipping the cover on one end of bumper and pulling over to the opposite side. Drill a 5/32" hole thru the Bumper Cover and into the bumper at each end at the wheel well. Install screws provided.

Speed Grille insert P.N. 950-7X847 is available for this Bumper Cover. Install Speed Grille into bumper cover before installing the bumper cover.