



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, Ca. 92626
Phone (714) 426-0590 Fax (714) 426-0591

950-70931
2006 - 2008
DODGE CHARGER
SIDE SKIRT KIT
2 PC SET

INSTALLATION INSTRUCTIONS

Pre-fit all pieces to the vehicle. Once you are assured you have the right body styling kit you may proceed. If uncertain call SSE to double check part number with your application. We highly recommend using masking tape anywhere the body kit will be touching the vehicle body to prevent scratches during pre-fit. Do any sanding, filing, or spacing necessary (BEFORE PAINTING) for a clean tight fit.

NOTE: Parts that have been drilled, installed, or painted are not returnable.

NOTE:

Check fit all body parts PRIOR to paint. Follow urethane prep instructions before painting. Take your time and pre-fit all pieces so that they will have a tight fit to the body.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	RT Side Skirt	1	Instruction Sheet	15 FT	1/2 Wide Double Sided Tape
1	LT Side Skirt	1	Urethane Prep Sheet	14	1/4" Black Plastic Push In Fasteners
1	Street Scene Decal	4 PKGS	Adhesion Promoter		

TOOL LIST	
Drill Motor, 1/8" & 1/4" Drill Bits	

1. Remove the OEM rocker panels by using an 1/8" drill bit and drilling out the two fasteners in each end in the wheel well. It will be necessary to remove the rear tires.
2. After the side skirts are prepped and painted double sided tape should be applied to the indentation on the inside of the skirt. This surface has to be clean and dry for the tape to properly adhere. The surface of the vehicle should also be prepped and cleaned for proper adhesion. The adhesion promoter should be applied to wherever tape will be used. When applying tape, make sure that tape is smooth and wrinkle free.
3. After applying the tape pull back approximately 1 inch of protective covering from the tape on each end. Make sure the film is sticking out.
4. Open doors and place the skirt gently on the vehicle and make sure you have it positioned correctly. You may use masking tape to hold in position. A second body will also be helpful.
5. Once you are sure of the position drill two 1/4" holes on each wheel well end and fasten using the push in fasteners.
6. While holding in position pull the tape you created while applying light downward pressure. Continue this taking care NOT TO TEAR OFF the tabs by pulling too hard. After all the film has been removed apply firm pressure all around to insure the tape has bonded properly.
7. From the underside of vehicle drill three 1/4" holes through the three tabs on skirts and into the mounting surface. Secure using the push in fasteners supplied.