



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-70935

2006 - 2007

DODGE CHARGER

HOOD

GEN 1 FIBERGLASS

### INSTALLATION INSTRUCTIONS

**NOTE:** Fit all parts before painting ( See special instructions for paint Prep. ) Parts that have been installed, prepped, or painted are not returnable.

**\*\*\*\* FIT HOOD BEFORE PAINTING \*\*\*\***

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

#### PARTS LIST

1	Fiberglass Hood	1	Instruction Sheet	1	Fiberglass Paint Prep Sheet
6	5/16" Lock Washers	1	Street Scene Decal	6	5/16" - 18 X 1" Bolts
6	5/16" Flat Washers				

#### TOOL LIST

Ratchet, Extension, 5/16" Socket

1. Remove hood from vehicle.
2. Remove hood pad.
3. Remove latch.
4. Cut Open Scoop on hood if desired.
5. Install hood pad to new hood. If scoop opening was cut open trim hood pad at opening location.
6. Install hood on vehicle. Use supplied hardware only. **DO NOT INSTALL LATCH AT THIS TIME.**
7. Align and adjust hood as necessary to fit. Adjust bump stops at this time.
8. Install latch and adjust as needed.