



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
 Costa Mesa, Ca. 92626
 Phone (714) 426-0590 Fax (714) 426-0591

950-70994
 2007
 GMC SIERRA
 HOOD SCOOP
 URETHANE
 TEXTURE COAT BLACK

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

NOTE:

Check fit all body parts PRIOR to paint. Follow urethane prep instructions before painting. Take your time and pre-fit all pieces so that they will have a tight fit to the body.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Hood Scoop	1	Instruction Sheet	8 FT	1/2" Wide Double Sided Tape
		1	Urethane Prep Sheet	1	Street Scene Decal
				2 PKGS	Adhesion Promoter

TOOL LIST	
NO TOOLS REQUIRED	

1. Color match hood scoop to vehicle. **DO NOT BAKE PAINT** shrinkage will occur causing scoop to deform.
2. Paint black the front of scoop to simulate an air opening.
3. Clean the mounting surface on hood scoop with alcohol and wipe surface with the adhesion promoter.
4. Apply the two sided tape on the bottom side of hood scoop as shown in the photo below.

PHOTO 1



5. Set the scoop onto the hood to assure positioning. Once you are certain of position remove the tape backing and apply pressure to the top side of scoop over the tape surface.