



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-73596

FORD MUSTANG 6 CYL

2005 - 2006

PLASTIC GRILLE SHELL
WITH CENTER MOUNT STYLE

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

NOTE: THIS KIT FITS V-6 MUSTANG ONLY

NOTE:

USE FORD OEM DRIVING LIGHTS P.N. 4R37-15200-AA AND P.N. 4R37-15200-AB

NOTE:

USE STREET SCENE WIRE HARNESS KIT P.N. 950-73591

KIT IS COMPLETE WITH EVERYTHING YOU NEED FOR A FACTORY LOOK INSTALLATION

PARTS LIST

1	Grille Shell	1	Instruction Sheet		

TOOL LIST

Flat Blade Screwdriver, Panel Removal Tool, Phillips Head Screwdriver

1. Open hood.
2. Remove the header panel between the grille and core support by prying up the center pin and then prying up the body of the retainer. See photos below.

PHOTO # 1



PHOTO # 2



Remove Panel

3. Remove the OEM grille by using a flat blade screwdriver and prying the tab on the fascia while depressing the locking tab on the grille. Do both sides first and then the bottom, gently pulling forward as you go. See photos below

PHOTO # 3



PHOTO # 4



4. Install the Street Scene wire harness at this time.
5. Set the Street Scene grille shell face down on the table. Be sure to cover table so that the grille does not get scratched. Place the fog lamps onto their mounting posts. Use the supplied screws and fasten them to the grille shell.
6. Install the Street Scene grille shell . Plug in the lamps sockets and align the tabs on grille with the slots in fascia.



7. Snap the entire grille into fascia
8. If needed the lamps can be adjusted at this time with a screwdriver turn adjuster screw clockwise or counter clock wise to adjust. See OEM specification manual for adjustment. See Photo below



9. Replace the top panel using the fasteners removed in step # 2. See Photo below.

