



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-73750

2005 - 2008

MUSTANG

REAR BLACKOUT PANEL

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST

1	Rear Blackout Panel	1	Instruction Sheet	1 PKG	3-M Adhesion Promoter

TOOL LIST

NO TOOLS NEEDED FOR INSTALLATION

1. Remove the Mustang emblem from the center of the deck lid. Fill the three mounting holes with a silicone sealant.
2. Clean the deck lid where the blackout panel will mount.
3. Remove the RED covering from the tape on the back side of blackout panel.
4. Open the package of the adhesion promoter and wipe the areas on the deck lid where the adhesive tape on the blackout panel will make contact.
5. Position the blackout panel to deck lid carefully. Apply pressure to panel to thoroughly adhere the tape.