



# STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue  
Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-74591 BLACK SATIN  
POWDER COAT  
&  
950-76591 BLACK CHROME  
&  
950-77591 SATIN FINISH  
&  
950-78591 CHROME FINISH  
2005 - 2006  
FORD MUSTANG 6 CYL.  
TO GT LOOK FRONT GRILLE

## INSTALLATION INSTRUCTIONS

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Care For Grilles	1	Instruction Sheet	8	Phillips Head Screws # 66126
		1	Street Scene Emblem	10	Push In Fasteners # 18379
1	Street Scene Grille Shell With Inserts				

TOOL LIST	

### NOTE:

USE FORD OEM DRIVING LIGHTS P.N. 4R37-15200-AA AND P.N. 4R37-15200-AB  
THESE CAN BE PURCHASED AT YOUR LOCAL FORD DEALER

### NOTE:

USE STREET SCENE WIRE HARNESS KIT P.N. 950-73591  
KIT IS COMPLETE WITH EVERYTHING YOU NEED FOR A FACTORY LOOK INSTALLATION

1. Open hood. Pry out the push in fasteners across the panel over thr grille. Remove panel. Depress the five tabs on the bottom side and the two on each side of the grille shell to remove the OEM grille. We suggest installing the wire harness at this time. Drill four 1/8" holes in each light mounting bosses. Install the lights purchased from your local Ford dealer with the screws provided. Tighten securely. DO NOT OVER TIGHTEN. You can strip the threads.
2. Install the Street Scene 6 cyl. Grille shell by aligning the tabs with the holes in the front fascia. Then " SNAP " into position. Plug in wire harness. Install the upper panel removed in step one. Use the new fasteners provided. Adjust lamps to OEM specification.

THE SPEED GRILLE™ may be covered by one or more of the following U.S. Patents: D427,119,D425,834,D421,585,D420,961,D420,960,D420,959, and D420,958 may be covered by one or more pending U.S. Patent applications.

09/29/05 SSE 950-74591 & 950-76591 & 950-77591 & 950-78591