



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, Ca. 92626
Phone (714) 426-0590 Fax (714) 426-0591

INSTALLATION INSTRUCTIONS

950-74776 BLACK POWDER
COAT
950-76776 BLACK CHROME
950-77776 SATIN FINISH
950-78776 CHROME FINISH
2009+
FORD F-150
XL,STX,XLT,FX4,ECOBOOST
SPEED GRILLE INSERT
MAIN GRILL

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

WARNING: Will Not Fit King Ranch Or Lariat With One Piece Flush Cross Member Pictured Below



PARTS LIST					
1	Speed Grille Insert	1	Instruction Sheet	12	11" Cable Ties
1	Care For Grilles				

TOOL LIST	
Ratchet, Extension, 10 MM Socket, Flat Blade Screwdriver, Side Cut Pliers	

1. Open hood.
2. Remove the six 10MM head nuts at top side of the grille shell at the hood line of vehicle.
3. Remove the 10 MM head bolt at the right and left lower corners of grille shell, where the shell attaches to the vertical metal brackets.
4. Carefully latch hood by pulling down on metal hood. DO NOT PULL on grille shell.
5. Remove the grille shell by carefully " Unsnapping " the top of grille shell from hood. There are five " Snap In " fasteners, two are located 2 1/2" in from each end, two at 15" in from each end and one in the center. Be carefull not to break the plastic tabs on grille shell.
6. Remove the " FORD " emblem by depressing the tabs on the back side of grille shell.
8. *Optional* Postion & re-install the factory oem Ford Emblem if desired.

THE SPEED GRILLE™ may be covered by one or more of the following U.S. Patents: D427,119,D425,834,D421,585,D420,961,D420,960,D420,959, and D420,958 may be covered by one or more pending U.S. Patent applications.

8. The Speed Grille will be secured to the grille shell using the cable ties supplied. They will be placed at each vertical side opening and at each vertical cross bar location. Install all 12 cable ties loosely before pulling snug. The ties will be " Looped " through the open holes in Speed Grille and then around the vertical cross bars. See "Arrows" in Photo Below.



9. Install grille shell back onto vehicle by snapping in the top to hood while inserting the threaded mounting studs into the slotted holes in hood. Make sure the top " Snap In " tabsnad fasteners are aligned correctly with the holes in hood before snapping in place. If not the tabs will bend and break off of grille shell.
11. ***Optional*** It is possible to cut out factory OEM center section taking carefull care to leave tabs for securing of Grille. Mark cuts first while installed, remove grill, carefully cut grill, reinstall SSE Grille Cuts need to be made at the above pictured "Oval's to remove center section.
12. Lift hood and install all nuts and bolts removed in step two and three.

