



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
 Costa Mesa, Ca. 92626
 Phone (714) 426-0590 Fax (714) 426-0591

INSTALLATION INSTRUCTIONS

950-76120 BLACK CHROME
 &
 950-77120 SATIN FINISH
 &
 950- 78120 CHROME FINISH
 SPEED GRILLE
 94 - UP CHEVY CK TRUCK
 MAIN GRILLE

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
2	Speed Grille Sections	1	Instruction Sheet	20	Attaching Clips # 71098
		1	Street Scene Emblem		

TOOL LIST
1/4" Drive Ratchet, 6" Extension, 7MM Socket, Phillips Head Screwdriver, Safety Glasses.

NOTE:

To install the Street Scene "Speed Grille", it will be necessary to remove the factory grille assembly from your truck. The "Speed Grille" was designed so that the original grids in the grill shell can be retained for an easy installation. Some may prefer to remove the grids for a fully custom look.

1. Before beginning installation be sure to wear proper eye protection.
2. Open hood.
3. Remove the four phillips head screws retaining the park/turn signal lamp assemble. Holding the lamp assemble in one hand, depress the lever on the bulb assemble and turn CCW to remove.
4. Reach into the openings in the grille where the lamps were mounted and grasp the light plug and turn 1/4 turn CCW and remove from amber marker lamp.
5. Reach in through upper grids in grille with a 7 MM socket and remove retaining screw.
6. Remove the four 7 MM screws attaching the grille at the top to the core support.
7. Through the Park/Turn signal lamp openings lift the lever at the bottom upward, to release the grille shell from the filler piece.
8. Lean the grille shell forward and depress the center lever to release the grille shell, and remove from truck.
9. Set grille on a soft, covered, clean work bench or table.
10. Remove the "Spedd Grille" from their packages. **Note:** Both grilles are the same they will go in upper or lower .
11. Grill will fit into grids of the OEM grille. Using eight of the clips provided, clip "Speed Grille" in from the backside of grille shell with flat side of clip facing away from grille. Locate clips at two inches from each end, top and bottom and center the others equally across. Make sure the "Speed Grille" is securely fastened and set tightly against the grids.
12. When using a grille shell with the grids removed, add 2 extra clips at center of insert.
13. Repeat this process for the lower section.
14. Re-install grille shell into the truck, reversing the removal procedure.
15. Test all lights for proper operation.

THE SPEED GRILLE™ may be covered by one or more of the following U.S. Patents: D427,119, D425,834, D421,585, D420,961, D420,960, D420,959, and D420,958 may be covered by one or more pending U.S. Patent applications.

TYPICAL CLIP INSTALLATION

