



# STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue  
Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

## INSTALLATION INSTRUCTIONS

950-76154 BLACK CHROME  
&  
950-77154 SATIN FINISH  
&  
950-78154 CHROME FINISH  
2007 - 2008  
BUMPER COVER  
SPEED GRILLE INSERT

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Speed Grille Insert	1	Instruction Sheet	4	Ladder Tie Straps # 10060
		1	Street Scene Emblem	1	Care For Grilles

TOOL LIST	
Drill Motor, 5/32 Drill Bit, Masking Tape, Side Cut Pliers	

1. Place masking tape on bumper as shown in the photo I below.

**PHOTO I**



2. Set the Speed Grille into the opening. Mark drilling positions as shown in photo below and drill 5/32 holes.

**PHOTO II**



3. Remove masking tape and install Speed Grille into opening from the backside, install tie straps into hole and through the loop in Speed Grille and into adjacent hole. DO NOT pull tight tie straps until all straps have been installed.

THE SPEED GRILLE™ may be covered by one or more of the following U.S. Patents: D427,119,D425,834,D421,585,D420,961,D420,960,D420,959, and D420,958 may be covered by one or more pending U.S. Patent applications.