

STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue Costa Mesa, Ca. 92626 Phone (714) 426-0590 Fax (714) 426-0591

INSTALLATION INSTRUCTIONS

950-76167 BLACK CHROME 950-77167 SATIN FINISH 950-78167 CHROME FINISH 2007 GMC YUKON OEM VALANCE SPEED GRILLE INSERT

VERY IMPORTANT! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Speed Grille Insert	1	Instruction Sheet	1	Care For Grilles
4	11" Ladder Ties	1	Street Scene Emblem		

TOOL LIST
Side Cut Pliers, Flat Blade Screwdriver, Drill Motor, 3/16" Drill Bit

- 1. Remove the tow hooks from vehicle.
- 2. Remove the two retainers above and below the tow hooks on each side of the center plastic panel in the bumper.
- 3. Remove the panel by depressing the ten locking tabs across the center of panel.
- 4. Drill four 3/16" holes as shown in the photo below.

PHOTO 1



5. Attach the Speed Grille by looping the ladder tie through the slotted hole, Speed Grille and then through the hole drilled in step four. See photo below for detail.

PHOTO 2



6. Install all ties first. Then pull tight and cut off excess.

THE SPEED GRILLE™ may be covered by one or more of the following U.S. Patents: D427,119,D425,834,D421,585,D420, 961,D420,960,D420,959, and D420,958 may be covered by one or more pending U.S. Patent applications.