



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-76177 BLACK CHROME

950-77177 SATIN FINISH

950-78177 CHROME FINISH

2007

CHEVY SILVERADO

OEM VALANCE

SPEED GRILLE INSERT

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

NOTE:

TOW HOOKS MUST BE REMOVED

PARTS LIST

1	Speed Grille Insert	1	Instruction Sheet	4	11" Ladder Ties
1	Care For Grilles	1	Street Scene Emblem		

TOOL LIST

Drill Motor, 3/16" Drill Bit, Side Cut Pliers

1. Remove the tow hooks from vehicle.
2. Drill eight 3/16" holes 4 on each side in valance as shown in the photo below.

PHOTO 1

DRILL 4 3/16" HOLES



3. From the back side of valance insert the ladder tie thru the upper hole drilled and then around the loop in the Speed Grille and then back into the lower hole.
4. Install all ties. Snug up by alternating between the four to tighten evenly. Cut off excess tie.

THE SPEED GRILLE™ may be covered by one or more of the following U.S. Patents: D427,119,D425,834,D421,585,D420,961,D420,960,D420,959, and D420,958 may be covered by one or more pending U.S. Patent applications.

06/28/07 SSE 950-76177 & 950-77177 & 950-78177