



# STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue  
 Costa Mesa, CA. 92626  
 Phone (714) 426-0590 Fax (714) 426-0591

## INSTALLATION INSTRUCTIONS

**950-77703 SATIN FINISH  
 &  
 950-78703 CHROME FINISH  
 SPEED GRILLE  
 FORD F-150  
 2000 - 2001 SUPER CREW  
 2 WD MODELS ONLY  
 F-150 & LIGHT DUTY F-250  
 WILL NOT FIT 4 WD TRUCKS  
 NOTE: FOR 4 WD  
 USE 950-77733**

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

**Note: No Drilling Is Required**

PARTS LIST					
1	Instruction Sheet	1	Got Street Scene Decal	10	Attaching Clips # 71098 ( B )
1	Street Scene Badge	1	Lower Grille Section	20	Long Attaching Clips # 71099 ( A )
1	Upper Grille Section	1	LH Center Grille Section	1	RH Center Grille Section

TOOL LIST	
Safety Glasses, 7mm Socket, Ratchet, Extension, Phillips & Flat Blade Screwdriver, Gloves, Grinder, Or File.	

1. Before beginning installation be sure to wear proper eye protection.
2. Remove the grille shell from the vehicle. Open the hood and remove the black ABS cover from grille to the radiator shroud. Remove the 8 phillips head screws on the retaining clips, lift cover up and remove the retaining clips.
3. Remove the turn signal / parking lamp assemblies by removing the 7mm head bolt at the inside corners behind grille above each lamp. Grasp lamp and pull straight to remove. Lift the locking tabs on bulb socket and turn 1/4 turn CCW to remove.
4. Remove the 10 phillips head screws securing the grille shell. Six are located across the top edge of grille and two are located at each side behind the parking / turn signal lamps.
5. Reach up through the bumper opening to the underside of the grille. Depress the metal retainers located 12 inches right and left of center to release the grille from the panel.
6. Gently pull grille shell forward and remove.

### Installing the Speed Grille

1. Set the grille shell on a soft, covered, clean work bench or table.
2. With the inside of grilleshell facing up, refer to photo for proper attaching clips location. Grind or file a notch 1/4" to 3/8" deep on the edge at each location mark with an ( X ). **Note:** Photo on other side.
3. Clip the Speed Grille inserts to the grille shell using the longer clips at the points marked " A ", and the shorter clips at the points marked " B ". **NOTE:** The flat side of the clip goes away from the Speed Grille.
4. Attach the Street Scene Badge to the Grille. Remove the protective cover on the face.
5. Re-install grille shell on the vehicle using the original fasteners.

**NOTE: PHOTO ON OTHER SIDE**



