

STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue Costa Mesa, CA. 92626 Phone (714) 426-0590 Fax (714) 426-0591

INSTALLATION INSTRUCTIONS

950-77740 SATIN FINISH
&
950-78740 CHROME FINISH
SPEED GRILLE
2000
FORD EXCURSION
MAIN GRILLE

VERY IMPORTANT! Read and understand all directions and check the following parts list before starting installation.

Note: Installation requires cutting out of center grille grids.

PARTS LIST							
28	Attaching Clips #71098	1	Instruction Sheet	1	Speed Grille Center Section		
		1	Street Scene Emblem	1	R.H. Speed Grille Section		
		1	Got Street Scene Decal	1	L.H. Speed Grille Section		

		TOOL LIST		
	1	Got Street Scene Decal	1	L.H. Speed Grille Section
	1	Street Scene Emblem	1	R.H. Speed Grille Section

Phillips Head Screwdriver, Sabre Saw, Sawzall, Or Hacksaw Blade Or Jab Saw (For cutting out grids) Satin Black Spray Paint, 120 Grit Sandpaper, 220 Grit Sandpaper, Masking Tape.

- 1. Open hood.
- **2**. Remove the four phillips head screws securing the Grille Shell across the top.
- **3**. Gently pull on the bottom side to release the snap in fasteners.
- **4**. Set the Grille Shell on a protective coverd bench or table.
- **5**. Cover the upper,lower and side chrome surfaces with masking tape to protect the finish. Cut out the center grids as close as possible without damaging the surounding ring.
- **6** . Carefully grind any protruding edges remaining. Sand the cut edges with 120 grit sandpaper, then finish sand with 220 grit.
- 7. Mask off the chrome part of the grille shell, then paint grille shell center ring with black paint.
- **8**. Remove the side grilles by depressing the tabs on the right and left sides.
- 9. Install the center Speed Grille section into the opening gently pushing the sides in untill it sets in fully. Install the attaching clips with the flat side away from the grille. Position the attaching clips as follows, install clips at the upper and lower center, at each end top and bottom and two centered between. Install three clips on each side, one in the center and one at the top and bottom.
- 10. Install the side grilles into the opening attach using four clips at the four snap points of the grille shell.
- **11.** Make sure all grilles are positioned properly and double check the clips.
- **12.** Install grille shell with Speed Grilles back into vehicle.

