

STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue Costa Mesa, Ca. 92626 Phone (714) 426-0590 Fax (714) 426-0591

INSTALLATION INSTRUCTIONS

950-77348 SATIN FINISH
950-78348 CHROME FINISH
950-79348 STAINLESS STEEL
2008
NISSAN TITAN
SPEED GRILLE INSERTS

VERY IMPORTANT! Read and understand all directions and check the following parts list before starting installation.

			PARTS LIST		
1	Center Speed Grille	1	Instruction Sheet	12	Ladder Ties # 10060
1	RT Speed Grille	1	Street Scene Emblem		
1	LT Speed Grille	1	Care For Grilles		

TOOL LIST
Flat Blade Screwdriver, Side Cut Pliers

- 1. Open hood. Remove grille shell by grasping the grille assemble and pulling to release the fastening points. Refer to service manual if you need further assistance.
- 2. Set grille shell on a protective covered bench or table.
- **3.** Unsnap the two air deflectors on each ends of the side openings. DO NOT break off the tabs. You will need to reattach these at a later point.
- 4. Remove the Nissan logo at this time.
- **5.** The Speed grille inserts will be fastened to the grille shell using the ladder ties provided. This will eliminate the need to separate the back half to the front half to install clips.
- **6.** Install the center Speed Grille into the opening. Use four ties to secure the Speed Grille to the grille shell. Insert the tie straps through the loop on the Speed Grille (Where it can not be seen from the front side) and around the X grids on the grille shell. Install all ties and then pull tight. Cut off excess.
- **7.** The side Speed Grilles will fasten in the same manner. After the side Speed Grilles are installed re-install the air deflectors removed in step three.
- 8. Re-install grille shell into vehicle.