



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

INSTALLATION INSTRUCTIONS

950-77512 SATIN FINISH
950-78512 CHROME FINISH
2002 - 2005
DODGE RAM HEMI
BUMPER GRILLE
INSERT

NOTE: USE P.N. 950-77508 ON NON SPORT MODELS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Speed Grille Insert	1	Instruction Sheet	6	Installation Clips # 71093
		1	Street Scene Emblem	6	Installation Clips # 71097
1	Grille Care Instructions				

TOOL LIST	
Phillips Screwdriver	

1. Open hood.
2. Remove the black ABS filler in bumper. Remove it by first removing the black phillip head retaining fasteners located on the top side of the filler. Reach in from the inside of bumper and release the bottom side of the filler and remove the filler. Re-install fasteners on the top side.
3. Install the Speed Grille into the opening. Attach the top side using the six 71097 clips (Narrower Clip). Attach the bottom side using the six 71093 clips. Refer to photo for installation procedure.
4. Install the Street Scene Emblem to grille face. Remove the protective cover.

TYPICAL CLIP INSTALLATION

