



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, CA. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-77723

2000 FORD EXPLORER

FACTORY VALANCE

SPEED GRILLE

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation. Installation time is approximately 10 minutes.

PARTS LIST

1	Speed Grille	1	Instruction Sheet	10	Attaching Clips (71098)
		1	Street Scene Decal	1	Got Street Scene Decal

TOOL LIST

NONE REQUIRED

1. Remove Speed Grille from it's protective package.
2. Install Speed Grille into valance opening from the front side.
3. Install the attaching clips from the back side with the flat side facing away from the grille. Install clips at each outer end, top and bottom and in the grille center top and bottom the remaining clips centered between.

