



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-77736

2002

FORD EXPLORER

MAIN GRILLE

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation. Installation time is approximately 1 to 1 1/2 hours.

NOTE:

CUTTING IS REQUIRED TO INSTALL THIS GRILLE INSERT

PARTS LIST

1	Speed Grille Section	1	Instruction Sheet	1	Street Scene Decal
1	Got Street Scene Decal	1	Street Scene Emblem		
10	Attaching Clips (Equal Length) 71098		5	Attaching Clips (Unequal Length) 71094	

TOOL LIST

Cutting Tool (I.E. Die Grinder, Coping Saw, Hack Saw Blade), Miss Hand Tools (To Remove Grille Shell)
Sandpaper, Spray Paint, Masking Tape.

1. Remove the grille shell from vehicle.
2. Tape over the chrome perimeter to protect from nicking or scratching.
3. Carefully cut out all of the verticle and horizontal bars. Cut close to edge but do not cut into perimeter.
4. Sand the entire perimeter and paint with spray paint. This can be painted black or silver.
5. Install the Speed Grille Insert into the opening from the front side of grille shell.
6. Attach from back side. Use equal length clips on the bottom and sides and the unequal length cilps on the top. Install the S/S emblem on the grille face and remove th protective cover on it.
7. Re-install grille into vehicle.

NOTE:

Speed Grille inserts are available for the lower bumper / valance openings order part number 950 - 77137

