



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-77745

FORD EXPLORER

2002

SPEED GRILLE

MAIN GRILLE

### INSTALLATION INSTRUCTIONS

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation. Installation time is approximately ? minutes.

PARTS LIST					
1	Speed Grille Section	1	Instruction Sheet	12	Installation Clips # 71098
1	Got Street Scene Decal	1	Street Scene Emblem		

TOOL LIST	
80 Grit, 120 Grit, 220 Grit Sandpaper, Misc. Tools, Cutting Disk, Or Hacksaw ( To Cut Plastic )	

1. Remove grille from front end. Refer to factory manual on this operation.
2. Tape the chrome face of grille to protect from scratching. " Cut Out " all horizontal and vertical bars from grille being careful not to cut into shell. Sand smooth with 80 grit sandpaper and then follow with 120 grit and 220 grit. Mask off chrome perimeter and paint to match vehicle or paint flat or satin black.
3. Install the Speed Grille into the opening from the front side, install 6 clips across the bottom 2 on each side and 4 across the top. Use the 3/4" clips with equal legs on bottom & sides.

### PLEASE NOTE:

This is a pre-production part, This part is hand made and fitment is not perfect.

