

STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue Costa Mesa, Ca. 92626 Phone (714) 426-0590 Fax (714) 426-0591 950-77811 1998 - 2000 FORD RANGER OEM LOWER VALANCE INSERT

INSTALLATION INSTRUCTIONS

VERY IMPORTANT! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST						
1	Speed Grille Insert	1	Instruction Sheet	5	Installation Clips # 71098	
		1	Street Scene Emblem	5	Installation Clips # 71097	
1	Grille Care					

TOOL LIST	
NONE	

- 1. Install the Speed Grille into the opening from the front side. Attach from the back side using the five shorter clips on the top and the five longer clips on the bottom. Refer to photo for installation procedure.
- 2. Install the Street Scene emblem to the grille face. Remove the protective cover on it.

TYPICAL CLIP INSTALLATION

